

IC7100BKT Icom IC-7100 CAT Control

Table of contents

Information on IC7100BKT	4
What it is	4
Connection with the PC	6
Changelog	7
Program registration	9
Functions	10
Configuration	11
Configuration	11
Configuration COM	12
Configuration PTT	13
Audio configuration	14
Language selection	15
Limits of band and mode	15
Startup programs	16
Main Window	17
Split	19
Memories	20
Management Memories	20
Editing Memory Bank	20
Memorize the current setting	22
Synchronization of the memories	23
Memory Import / Export	23
Import memory from dstarinfo.com	25
Scanner	26
Scanner	26
Scansion Log	27
Scanner Preset	28
Frequency to ignore	29
Skeds	30
Skeds	30
Activation sked	31
Generate recur skeds	31
Delete skeds	32
Bands	33
Set Mode	33
CW Setting	34
Setting	35
Utility	36
AutoCQ	37
Plug-in	37
Plug-In Management	38
OnAir	39
Hook Clipboard	40
PTT	40
Recorder audio	41
QuickSet	42
DV - DStar	44

Custom Key	44
Various	45
List	45
DTCS	45
Tone	46
DUP	47
Chosen VFO	47
OFF-LINE Mode	47
Band Stacking	48
Numerical Input	49
Progress Indicator	49
Function Full Version	49
Remote management by TCP/IP	50
Remote management by TCP/IP	50
BKTClient	51
Access Control	51
BKTClient	52
Configuration	52
BKTServer	53
BKTRS232 Alternative serial driver	55
Interfacing with other programs	55

Information on IC7100BKT

Created with the Personal Edition of HelpNDoc: [Upgrade your help files and your workflow with HelpNDoc's WinHelp HLP to CHM conversion](#)

What it is


IC7100BKT

[Top](#) [Next](#)

What it is

[Top](#) [Next](#)

ATTENTION: this guide has been translated by an automatic system, excuse



The IC7100BKT CAT program controls the ICOM IC-7100 transceiver using a personal computer running Microsoft Windows XP, Vista, 7, 8, 8.1 32 and 64 bit.

The main window has the most commonly used commands.

When the cursor hovers over a button or slider a pop-up balloon will display a short description of its function.

Right clicking on a slider will allow a numerical value to be input for that setting

The LED's located at top left of the window blink at the data transfer rate between the program and the Txvtr.

Press F1 key to call this guide..

Connection with the PC

Connection with the PC

[Top](#) [Previous](#) [Next](#)

For communication with the PC board using the USB connection of the RTX installing drivers Icom, alternative interface that you can buy as an accessory ICOM, or build following the diagram in Figure 1 or Figure 2

Different communication rates can be selected dependent on your PC (the minimum recommended speed setting for the




Fig. 1




Fig. 2

Created with the Personal Edition of HelpNDoc: [Effortlessly Spot and Fix Problems in Your Documentation with HelpNDoc's Project Analyzer](#)

Changelog

Versions

[Top](#) [Previous](#) [Next](#)

24/07/2014 Ver. 1.0.0

First official release

25/07/2014 Ver. 1.1.0

Adding the import function of the memories from www.dstar.info

Fixed minor bugs.

26/07/2014 Ver. 1.1.1

Fixed minor bugs.

29/07/2014 Ver. 1.1.2

Correct setting DUP + or DUP- in DV mode when active VFO A or B

02/08/2014 Ver. 1.2.0

Adding DV - DStar support

09/08/2014 Ver. 1.3.0

Adding data mode

Improved window of management of DV - DStar

10/08/2014 Ver. 1.3.1

Correct setting remote data mode.

13/08/2014 Ver. 1.3.2

Include BktExtension71k ver. 1.17.0.

17/08/2014 Ver. 1.3.3

Fixed bug about displaying child windows (DV, PTT, Audio Recorder and Quick Set).

18/08/2014 Ver. 1.3.4

Improved Power On and Power Off function.

11/10/2014 Ver. 1.3.5

Automatic restart after configuration.

18/12/2014 Ver. 1.3.6

Improved copy/cut/paste of memories.

28/12/2014 Ver. 1.3.7

Correct trial version for 2015.

25/01/2015 Ver. 1.4.0

Added support for OnAir status on HrdLog and EnzoLog.

Improved loading of registration keys.

Changed the default font with Arial 9 points.

Improved the installation.

04/02/2015 Ver. 1.4.1

After a software tune is set correctly the Data mode.

09/05/2015 Ver. 1.5.0

Added CAT support for HrdLog.

19/07/2015 Ver. 1.5.1

Support BKTEExtension 1.18.0

19/08/2015 Ver. 1.6.0

Improved AutoCQ

In tab Set Mode, adding the manage input of the modulation

23/08/2015 Ver. 1.6.1

Correct label keys AutoCQ

02/09/2015 Ver. 1.7.0

Adding [Custom Key](#)

Correct import memories from CSV column "Selected"

Support BKTEExtension 1.19.0

10/09/2015 Ver. 1.7.1

Improved [Custom Key](#) windows

10/10/2015 Ver. 1.7.2

Support BktExtension 1.20.0

12/12/2015 Ver. 1.8.0

Added automatic call on CW in the function [AutoCQ](#)

03/01/2016 Ver. 1.8.1

Support BktExtension 1.21.0

27/02/2016 Ver. 1.8.2

View the version in use (Free, Full or Trial)

03/04/2016 Ver. 1.8.3

Correct filter settings when changing band

18/08/2016 Ver. 1.8.4

New version 1.0.1 of OnAir

Correct link to the forum

30/04/2017 Ver. 1.9.0

Added 1KHz note for software tuning

Added the option to send by enabling USB input during 1KHz software tuning or 1750Hz note output

23/07/2017 Ver. 1.10.0

Added preamplifier setting 1 and 2

10/09/2017 Ver. 1.10.5

Fixed bug on AutoUSB

Added flag "Keep on-front" on Custom Key

07/10/2017 Ver. 1.11.0

Support BktExtension 1.22.0 for BktDxCluster Android

21/08/2018 Ver. 1.11.1

Link update

21/05/2019 Ver. 1.11.2

Fixed the step in the Scanner function

26/05/2019 Ver. 1.11.3

Correct sort of grid in edit memories window

Added automatic power on of RTX in activation of a sked

22/09/2019 Ver. 1.11.4

Improved Filter management with Mode change

02/01/2021 Ver. 1.11.5

Improved audio device management

02/06/2023 Ver. 1.11.6


Correct key loading for the trial version

Created with the Personal Edition of HelpNDoc: [Free PDF documentation generator](#)

Program registration

Program registration

[Top](#) [Previous](#) [Next](#)



All the information on the registration are on: <http://www.maniaradio.it/en/ic7100registrazione.html>.

The key for free version is totally free and allows the use of a lot of the functions of the program and to try for 30 days the functions of the full version.

In order to install the activation key:

1. Save in a folder the file <call.IC7100bkt.dat> attached to the email received (call is yours callsign specified in the registration form)
2. Start program IC7100BKT
3. Click on the key [I have the key, load it]
4. Select the folder and the file saved to point 1 and press [Open]
5. Backup the activation key on a floppy or a removable device

Created with the Personal Edition of HelpNDoc: [Effortlessly Spot and Fix Problems in Your Documentation with HelpNDoc's Project Analyzer](#)

Functions

Created with the Personal Edition of HelpNDoc: [Create HTML Help, DOC, PDF and print manuals from 1 single source](#)

Configuration

Created with the Personal Edition of HelpNDoc: [Full-featured Help generator](#)

Configuration

Configuration

[Top](#) [Previous](#) [Next](#)

General configuration of the program.

Is important that the values of communication of the serial port and the address CI-V that has to exactly correspond with the values CI-V BAUD and CI-V ADDRES in the IC7100. You advises to care the parameter CI-V BAUD of the transceiver as Auto.

[COM] Serial port and external drive setting.

[PTT] PTT and antenna tuner setting.

[Audio] Audio setting.

[Address CI-V] Exadecimal address of interface CI-V (default = 88).

[S-Meter Calibration] Set up the values [Limit down] and [Divisor] to make to correspond the value read by the S-Meter of the program with that of the RTX.

[Colors] Choose the colors for display and the keys.

[Communication with teh Clipboard] Parameters for a correct exchange of the data with the clusters programs

[UTC Offset] Points out the bewilderment in times among the time UTC and that local. If put to [Auto] for the calculation of the time UTC is used the settings of Windows.

[Log] Generally must be let empty, point out the name of a file in which to save the Log of exchange dates on the serial port.

[Use the memory E99 for the temporary data] If select this option the memory <99> of the bench <E> its used to support of some functions like the control of the state of the DUP and the SPLIT.

[Synchronize clock on startup] Enabling this option, the RTX clock is synchronized with one PC to the first change of minute from the start of the programme.

[Change Language] Select the language.

[Timing scan control (0 for Auto)] Time in milliseconds for scanner manage function, leave 0 for automatic control.

[Latency time (0 for Auto)] Work time in milliseconi, set to zero for the automatic calculation to the start. A too low latency time might cause the data loss between the pc and the rtx, a too high time slows down the reading of the data of the rtx.

[Enable ToolTips] Enable the help ballons

[Check for updates every] Range of days for automatic updates of the program. Set to 0 not to check.

[Font Main Window] Select the font to be used for the main window, [Size] to enlarge or shrink the main window size.

[Font Memory, PTT e Audio Recorder] Select the font to be used for the secondary window, [Size] to enlarge or shrink the secondary window size.

[Restore Default] Restore the default parameters of the program.

Created with the Personal Edition of HelpNDoc: [Easy EPub and documentation editor](#)


Configuration COM

Configuration

[Top](#) [Previous](#) [Next](#)

Configuration COM

[Top](#) [Previous](#) [Next](#)



These parameters are essential for a good operation of the program. If a transistor [interface](#) is used it is worthwhile to plan RTS and DTR to ON, with an [interface](#) with the MAX232 it is recommended to plan to 19200,N,8,1 with RTS and DTR to OFF. If you have other interfaces connected on the same serial ports (es. interfaces for PSK31), it needs RTS or DTR to OFF to avoid to send in transmission the RTX when he enters the program.

For optimal operation of the program select 9600 or 19200 baud.

Its possible to select an external driver (es. [BKTClient](#) for the remote management by TCP/IP), in such case will be activated the key [Driver Setup].

Selecting the driver **BktDummy** the program will work in dummy mode also without the RTX connected.

[Serial Port Mode]: for USB interfaces or for RIGtalk of West Mountain Radio use MODE 1.

If there are connection problems try this:

- Change the [Serial Port Mode]
- Change the RTS and/or DTR
- Down the connection speed from 19200 to 9600 BAUD or lower
- Try to use [BKTRS232](#) driver
- Look here : <http://www.iz2bkt.com/forum/viewtopic.php?f=26&t=328>

Created with the Personal Edition of HelpNDoc: [Effortlessly upgrade your WinHelp HLP help files to CHM with HelpNDoc](#)

Configuration PTT

Configuration

[Top](#) [Previous](#) [Next](#)

Configuration PTT

[Top](#) [Previous](#) [Next](#)

IC7100BKT - PTT Setup

Tune software emulation

Mode: RTTY Power: 20 % Seconds: 5

Use 1KHz tone ☒

Switch USB input while tuning or transmit 1750Hz ☒

Key for PTT: NONE ☐ Key PTT keep in front

Clipboard

PTT ON: @[on]@

PTT OFF: @[off]@

OK Cancel

Configuration of the management of the PTT, that is the possibility to send the RTX in transmission through the program.

[Tune software emulation] Put the RTX in transmission for the time and with power and mode specifies allowing to tune the antenna.

[Use 1KHz tone] Sends 1 KHz note to desired power for the time given to promote the tuning

[Switch USB input while tuning or transmit 1750Hz] When it starts transmitting enables USB input, at the end, rehabilitates the previous input

[Key PTT] Select the key of the keyboard to use like PTT, NONE in order not to use any.

[Key PTT keep in front] Put the window of the PTT always in front of all the other windows.

Clipboard

[PTT ON] Sequence of characters that, if copied in the clipboard of Windows, put the RTX in transmission.

[PTT OFF] Sequence of characters that, if copied in the clipboard of Windows, put the RTX in reception.

Created with the Personal Edition of HelpNDoc: [Effortlessly Convert Your Word Doc to an eBook: A Step-by-Step Guide](#)


Audio configuration

Configuration

[Top](#) [Previous](#) [Next](#)

Audio configuration

[Top](#) [Previous](#) [Next](#)



[Enable audio support] Enable/disable the audio support.

[Audio Input] Chose the audio device for input. Default for windows default device.

[Audio Output] Chose the audio device for output. Default for windows default device.

[Audio format] Choose the audio format to use for the recording. To record vocal communications is preferred to install a CoDec MP3 and choose the low quality. With the configuration in figure, an hour of recording occupies approximately 3,5Mb of disc. To record digital communications them convene to use format PCM, in this case the occupation on disc will be much high. The extension of the files audio is WAV.

[Folder for audio files] Folder for saves the audio files. If the field is empty, it comes used the folder where the program is installed.

[Name of audio file] it is possible to specify a default name to use for the files audio, if he leaves AUTO, to the beginning of every recording, a file will be produced by the name BKTymmddhhmmss.WAV, where yy=year, mm=month, dd=day, hh=hour,

mm=minute and ss=second of beginning recording.


[Keep recorder in front] If activated, the Audio Recorder is always maintained in front of all the other windows.

Created with the Personal Edition of HelpNDoc: [Converting Word Docs to eBooks Made Easy with HelpNDoc](#)

Language selection

Language selection

[Top](#) [Previous](#) [Next](#)



Select from the list the preferred language.

You can add languages by following this procedure:

1. Copy the file English.lng in the name of the language you want (eg. Franch.lng)
2. Edit with Notepad or BKTLocalize the file created in step 1
3. For each row, after the equals sign, put the phrase translated being careful not to change the codes (%1-% s-% n-\n-etc. ..)
4. Send me the translated file if you want to be published on the website of the programme

Created with the Personal Edition of HelpNDoc: [Step-by-Step Guide: How to Turn Your Word Document into an eBook](#)

Limits of band and mode

Configuration

[Top](#) [Previous](#) [Next](#)

Limits of band and mode

[Top](#) [Previous](#) [Next](#)

IC7100BKT - Band and mode limits

General coverage of RTX

From Hz To Hz

Band : ▾

From Hz To Hz

Mode	Low limit Hz	High limit Hz
CW	<input type="text" value="1.800.000"/>	<input type="text" value="1.838.000"/>
RTTY	<input type="text" value="1.830.000"/>	<input type="text" value="1.834.000"/>
LSB	<input type="text" value="1.838.001"/>	<input type="text" value="2.000.000"/>
USB	<input type="text" value="0"/>	<input type="text" value="0"/>
FM	<input type="text" value="0"/>	<input type="text" value="0"/>

From this mask it is possible to define the limits of coverage for the RTX and for every radioamateur bands.

[General Cover of RTX] Point out the minimal and maximal frequency supported by the RTX.

[Read from RTX] Read the min and max frequencies of radio. Please note that these frequencies are not necessarily the absolute min and max.

[Band] To choose the amateur band to modify.

[From] [To] The minimal and maximum frequency of the selected band.

For every mode of emission to indicate wrap it of frequency used inside of the selected band following the amateur BANDPLAN.

[Restore default] Restore the default values of the program.

ATTENTION: all the values of frequency are in Hz.


Startup programs

Configuration

[Top](#) [Previous](#) [Next](#)

Startup programs

[Top](#) [Previous](#) [Next](#)



The programs specified in this window will be started to the start of IC7100BKT.

For every program to introduce:

Description: description of the program

Program: program inclusive of path, ex. c:\windows\notepad.exe

Parameters: parameters for the program

[...] find the program

[OK] closes the window saving the possible changes

[Delete] delete the selected program

[Save] save the input

[Abort] closes the window without saving the possible changes


Created with the Personal Edition of HelpNDoc: [Maximize Your PDF Protection with These Simple Steps](#)

Main Window

Main Window

[Top](#) [Previous](#) [Next](#)

ATTENTION: this guide has been translated by an automatic system, excuse



In the main window they are present the commands of great use, **stopping itself with the mouse on a key or a slider of the command, while, click with the mouse right key on the sliders or on numerical values to input the [value](#).**

The two Led green/red places up to right of the window blink to the passage of data between program and RTX.

As to change frequency:

- Click with the right mouse button on the frequency, enter the frequency in Hz and press the Enter key.
- Use the keys + and - dispose to the edges of the frequency display.
- Position the mouse on the frequency display and use the wheel of the mouse.
- Use the function keys F2 through F9 and Shift.

Information on the main window:

- Date and hour in local format and UTC.
- Information on the Radio station and Operator.
- Tuning bar. Click and drag the pointer to change frequency. The bar will become of red color when the RTX is syntonized. Click with the mouse right key for [numerical input](#) of the frequency.

Keys:

All the keys are easily identifiable, signal:

[Mini] Hides all windows and activates the interface minimized (see below)

[Sync.] Reset and restart the connection between RTX and program.

[Polling] If active periodically reads the values of the rtx controls, if deactivated controls only SMeter, Frequency and LAN/internet or you are using a slow connection to the rtx is recommended to disable Polling.

[Store] [Memorizes the active values.](#)

[Band Stacking] Saves/Recalls frequency and operating mode from the operating stacks.


[Rev.] Active only if active DUP or DUP-. Swap frequency transmission with receive.

[Help] Visualizes this guide.

[Exit] Exits from the program.

[Hook Clipboard] Enable/disable the elaboration of the data of the clipboard of Windows.

INTERFACE MINIMIZED:



Activated by the button [Mini] allows to manage all functions of the radio, taking up little space on the screen.

[Full] Restore main window

Created with the Personal Edition of HelpNDoc: [Add an Extra Layer of Security to Your PDFs with Encryption](#)


Split

Functions

[Top](#) [Previous](#) [Next](#)

Split

[Top](#) [Previous](#) [Next](#)



Management of the split, that is, the possibility to receive and to transmit inside on two various frequencies of the same band.

[Delete] Cancels the selected split

[New] Predisposes the fields for the input of a new split

[Save] Saves the split

[Active] Active the split

[Description] Description of the split

[Split] Offset value of reception frequency to set the transmission frequency, mode and

transmission filter

For disable the Split use the relative key on [main window](#).

ATTENTION: the offset frequency is in Hz.

Created with the Personal Edition of HelpNDoc: [Import and export Markdown documents](#)

Memories

Created with the Personal Edition of HelpNDoc: [Experience the power of a responsive website for your documentation](#)


Management Memories

Memories

[Top](#) [Previous](#) [Next](#)

Memories Management

[Top](#) [Previous](#) [Next](#)



Management of the 5 memory banks. It's possible to associate a name to every bank.

[Bank n] It opens/Closes [window of management of the memories](#) of this bench
[Synchronize] Synchronize the memory database with the memory of the RTX

[Memory Mode] Puts the RTX in memory mode and enable [Bank] and [Memory]

Created with the Personal Edition of HelpNDoc: [Converting Word Documents to eBooks: A Step-by-Step Guide with HelpNDoc](#)

Editing Memory Bank

Memories

[Top](#) [Previous](#) [Next](#)

Editing Memory Bank

[Top](#) [Previous](#) [Next](#)

IC7100BKT - Memory Bank C - DStar

△	Description	Rx Freq.	Rx Mode	Rx Filter	Rx Tone	Rx TSqL	Rx DtcS	Rx Ac.T.	Rx Dup	^Tx	Tx F
09	IR8BA C Talk	145.787.500	DV	1	88.5	88.5	023-NN		600	DUP-	145.
10	IR2UX B Talk	431.667.500	DV	1	88.5	88.5	023-NN		1600	DUP+	433.
11	IQ2GM B Talk	431.612.500	DV	1	88.5	88.5	023-NN		1600	DUP+	433.
12	IR2UFH B Talk	430.137.500	DV	1	88.5	88.5	023-NN		1600	DUP+	431.
13	IR2UDY B Talk	431.437.500	DV	1	88.5	88.5	023-NN		1600	DUP+	433.
14	IQ4GS B Talk	431.525.000	DV	1	88.5	88.5	023-NN		1600	DUP+	433.
15	IQ4GS C Talk	144.862.500	DV	1	88.5	88.5	023-NN		600	DUP+	145.
16	IR1UAW C Talk	144.925.000	DV	1	88.5	88.5	023-NN		0	DUP-	144.
17	IR1UAW B Talk	430.912.500	DV	1	88.5	88.5	023-NN		5000	DUP+	435.
18	IR4UAJ B Talk	430.237.500	DV	1	88.5	88.5	023-NN		1600	DUP+	431.
19	IR4UBP B Talk	430.425.000	DV	1	88.5	88.5	023-NN		5000	DUP+	435.
20	IR4MO C Talk	145.562.500	DV	1	88.5	88.5	023-NN		600	DUP-	144.
21	IR4UBL B Talk	430.562.500	DV	1	88.5	88.5	023-NN		5000	DUP+	435.
22	IR4URE B Talk	430.262.500	DV	1	88.5	88.5	023-NN		5000	DUP+	435.

Memory : 19 IR4UBP B Talk ☐ Selected DUP + DUP - Split

RX

Frequency	Mode	Filter	Tone	TSqL	DtcS	Rx Tone	Rx TSQ L	Rx DTCS
430.425.000	DV	1	88,5	88,5	023-NN			
Digital SQL	D.Code	Call Sign	RPT1 Call	RPT2 Call	Data Mode	DUP Set		
OFF	0	CQCQCQ	IR4UBP B	IR4UBP G	OFF	5.000		

TX

Frequency	Mode	Filter	Tone	TSqL	DtcS	Tx Tone	Tx TSQ L	Tx DTCS
435.425.000	DV	1	88,5	88,5	023-NN			
Digital SQL	D.Code	Call Sign	RPT1 Call	RPT2 Call	Data Mode	DUP Set		
OFF	0	CQCQCQ	IR4UBP B	IR4UBP G	OFF	5.000		

Every variation, insertion and cancellation effected in this window will be reflected in the memories of the RTX (excluded the

Click on the description of the column, you can change sorting display of memories (for example, description, frequency, m

Double-click the cell to edit.

[Delete] Cancel the selected memory.

[Save] Save the selected memory.

[Transfer to VFO] Transfer RX Frequency, Mode and Filter to the VFO-A and the TX Frequency, Mode and Filter to the VFO-B.

[Save and Active] Save the selected memory and puts the RTX in Memory mode.

[Synchronize] Synchronize this memory bank with the RTX.

[Print] Print the memories as visualized in the grid.

Using the command Copy, Cut and Paste is possible to duplicate or to move memories from a bench to the other or one position to another.

[Copy] Copy the memory selected in the clipboard.

[Cut] Copy the memory selected in the clipboard and will cancel it when it comes chosen the function Paste.

[Paste] Save the memory in the clipboard on that one selected.

[Delete Block] Deletes a block of memories

[Remap] Remaps memories second sorting chosen: click the heading of the column you want to choose the sort order, and then click the memory you want to remap.

[Save To File] Saves the current memory bank in a file

[Load From File] Load current bank memory from a file previously saved with [Save to File]. WARNING current memories will be overwritten.

[Export] Export the memory bank in a file CSV.

[Import] Import the memory bank from a file CSV or a ARRL TravelPlus file. WARNING current memories will be overwritten.

[Import dstarinfo.com] Import memories downloaded from www.dstarinfo.com

[Memory Mode] Put the RTX in Memory mode and enable the selected memory.

Click on the description of the column for change the ordering of visualization of the memories.

Created with the Personal Edition of HelpNDoc: [Easy EPub and documentation editor](#)


Memorize the current setting

Memories

[Top](#) [Previous](#) [Next](#)

Memorize the current setting

[Top](#) [Previous](#) [Next](#)



[Select Memory Bank] Select the memory bank to use

[Select Memory] Select the number of the memory to use

[Editing memory bank](#) of the selected bank, you will have to insert the description of the memory and press [Save].

Select an empty memory otherwise the values will not be stored.

Created with the Personal Edition of HelpNDoc: [Write EPub books for the iPad](#)

Synchronization of the memories

Memories

[Top](#) [Previous](#) [Next](#)

Synchronization of the memories

[Top](#) [Previous](#) [Next](#)

The synchronization serves to align the content of the database with the memories of the RTX.

[Memory bank]

Select the memory bank to Synchronize

[If memory exist on RTX and on database execute]

Select the action to execute if the memory is

present in the RTX and in the database of the PC:

- Nothing = leaves unchanged database and RTX
- Overwrite database = overwrite the memory of the database with that of the RTX
- Overwrite RTX = overwrite the memory of the RTX with that of the database

[If blank in database delete from RTX]

If the memory in the database is empty it will be

cancelled in the RTX. To cancel the memory the RTX will come put in Memory Mode and selected the memory by to cancel.

[If blank in RTX delete from database]

If the memory in the RTX is empty it will be

cancelled by the database.

Created with the Personal Edition of HelpNDoc: [Streamline Your Documentation Process with HelpNDoc's Intuitive Interface](#)


Memory Import / Export

Memory Import / Export

[Top](#) [Previous](#) [Next](#)

Memory Import / Export

[Top](#) [Previous](#) [Next](#)



Import or Export the bench of memory in a CSV format file. The format CSV can be used with Microsoft Excel.

[Field separator] Character to be used for separating a field from the other.

[Decimal separator] Character to be used for pointing out the decimal value (Es. 87.5 use the point)

[File] Select the file to create or to use

[...] Press for browsing the folders to the search of the file

[Start] Begin the conversion

[Close] Close this window

[Files exported from ARRL TravelPlus] Used to import the memories generated with the ARRL TravelPlus programme

[Use the Sequence number for memory] Use the Sequence field as the number of memory (maximum 99)

[Use memories from the number 1] Import the memories from number 1 of the bench current and ignoring the sequence field

To successfully import the memories, use the function Export Repeater Data of the TravelPlus programme with the settings following :

Select Columns and Max. Width

	Truncate	Max.
<input checked="" type="checkbox"/> Sequence Number	6	6
<input type="checkbox"/> Band	25	25
<input type="checkbox"/> Country	6	6
<input type="checkbox"/> State	24	24
<input type="checkbox"/> Region	30	30
<input type="checkbox"/> Location	29	29
<input checked="" type="checkbox"/> Output Frequency	10	10
<input checked="" type="checkbox"/> Input Frequency	10	10
<input checked="" type="checkbox"/> Call Sign	13	13
<input type="checkbox"/> Repeater Notes	31	31
<input checked="" type="checkbox"/> CTCSS Tones	7	7
<input type="checkbox"/> Sponsor	30	30
<input type="checkbox"/> Distance	8	8
<input type="checkbox"/> Bearing	8	8

Select All Clear All

Reset Default Max. Widths

Column Sequence

To change the sequence in which columns are exported, highlight the column name and up it up or down in the list:

Sequence Number
Output Frequency
Input Frequency
Call Sign
CTCSS Tones

Reset Default Sequence

Format

☒ Comma Delimited File
☐ Tab Delimited File
☐ HTML
☐ XML Spreadsheet

☒ Include Column Headings

Pre-Defined Formats

Radio Programming Format

User-Defined Band Format

Note: Data can also be selected from a list by row selection or Edit > Select All Columns. Then use Edit > Copy to copy to clipboard for pasting into other applications such as Excel.

Created with the Personal Edition of HelpNDoc: [Converting Word Docs to eBooks Made Easy with HelpNDoc](#)

Import memory from dstarinfo.com

Import Memory from dstarinfo.com

Field separator ; Decimal separator ,

File :\\Download\\Memory List For IC-7100 (2).csv ...

Start from memory (1 to 99) 18


For Help press F1 key

Start Close

To successfully import the downloaded memories from www.dstarinfo.com you must export it properly by choosing the right values as shown below.

The memories will be imported sequentially starting from the memory in the current bank specified in [Start from memory].

WARNING: Any memories will be overwritten by those imported.



D-STAR Downloads

D-STAR Info Downloads Version 1.92 - 8 April 2014

For which radio?

Which type list do you want?

Select the module frequencies that you would like listed

☒ VHF (144-150 MHz)

☒ UHF (430-450 MHz)

☐ UHF (1.2 GHz)

☐ UHF (1.2 GHz) High-Speed Data

What section of the world would you like the download to cover?

Select by Subregion

Choose File Format

☐ "," as field separator and "." as decimal mark (A model/software)

☒ ";" as field separator and "." as decimal mark (E model/software)

Created with the Personal Edition of HelpNDoc: [Make the switch to CHM with HelpNDoc's hassle-free WinHelp HLP to CHM conversion tool](#)

Scanner

Created with the Personal Edition of HelpNDoc: [Produce online help for Qt applications](#)

Scanner

Scanner

[Top](#) [Previous](#) [Next](#)

Scanner

[Top](#) [Previous](#) [Next](#)

Split	Memories	Scanner	Skeds	Bands	Set Mode	Utility	Auto CQ	Plug-In	Info
Start frequency :		<input type="text" value="434.000.000"/>	Hz	Mode	<input type="text" value="FM"/>	Filter	<input type="text" value="1"/>		
End frequency :		<input type="text" value="435.000.000"/>	Hz	Step	<input type="text" value="12.5 KHZ"/>	Speed	<input type="text" value="Slow"/>		
Scan Memory <input type="checkbox"/>		Bank	<input type="text" value="E ->"/>	Only selected <input checked="" type="checkbox"/>		Fr. Exc.	<input type="checkbox"/>	Preset	<input type="checkbox"/>
Start <input type="button" value="Start"/>		Stop <input type="button" value="Stop"/>	Min.Sig.: <input type="text" value="S0"/>	Pause 1	<input type="text" value="+0"/>	\$ <input type="button" value="Log"/>	<input type="button" value="Record"/>	<input type="button" value="View Log"/>	
				Pause 2	<input type="text" value="0"/>	\$			

Executes a cyclical search between two frequencies or from the memories of a bank.

[Start frequency]	Frequency of beginning search
[End frequency]	Frequency of end search
[Mode]	Operating mode with which searching, choosing FM or AM it is possible to use the SQL to stop the search
[Step]	Step of increment of the frequency
[Filter]	Filter using during the search
[Speed]	The search speed can be Fast or Slow
[Scan Memory]	Executes the search between the memories of the selected bank
[Bank]	Bank to use
[Only selected] chosen	Execute the search only using the memories marked Selected of the bank
[Fr.Exc.]	Allows you to specify the frequency to be excluded from scanning. <div data-bbox="459 667 547 696" data-label="Image"> </div> The button is red if the table contains frequencies.
[Preset]	Click Preset to manage the database of pre-set scan.
[Start]	Start the search
[Stop]	Interrupt the search
[Min.Sig.]	Minimal intensity of signal them because it is considered valid
[Pause 1]	Pause in seconds after to have found a signal and before resuming the search: 0 = Wait until that SQL passes in ON -1 = Use the resume of the IC-7100 and ignore Pause 2
[Pause 2]	Pause in seconds before passing to the successive frequency after that SQL is returned ON.
[Log]	Enable/disable scansion log
[Record]	Enable/disable the audio recording. The key is active only if it is active the audio support .
[View Log]	scansion log

ATTENTION: all the frequencies are in Hz.

Scansion Log

Scanner

[Top](#) [Previous](#) [Next](#)

Scansion Log

IC7100BKT - ScanLog						
Day	Month	Year	Time UTC	Freq./Mem.	Signal	Audio File
22	07	2014	15:16:00	145.018.000	S 0	20140722_151600_145018000_S 0.wav
22	07	2014	15:16:11	145.090.000	S 9+20	20140722_151611_145090000_S 9+20.wav
22	07	2014	15:16:23	145.477.000	S 3	20140722_151623_145477000_S 3.wav
22	07	2014	15:16:34	145.477.000	S 3	20140722_151634_145477000_S 3.wav
22	07	2014	15:16:45	145.684.000	S 8	20140722_151645_145684000_S 8.wav

Activate

Play

Delete

Synchronize Wav

Close

Play All

Delete All

Print

This is the log build from the [scansion](#).

For every valid signal is recorded:

- Date in Day, Month and Year
- Hour UTC
- Frequency
- Intensity of the signal
- Audio recording (only if active)

[Activate]	Active the selected frequency
[Play]	Reproduce the recording of the selected line.
[Delete]	Delete the selected line and the relative audio file
[Synchronize Wav]	Delete or add lines based on the audio file present in the log folder
[Close]	Close this window
[Play All]	Reproduce all the recordings in sequence
[Delete All]	Delete all the lines and all the audio file
[Print]	Print the grid.

Click on the description of the column for change the visualization ordering.

Created with the Personal Edition of HelpNDoc: [Free help authoring tool](#)

Scanner Preset

Scanner

[Top](#) [Previous](#) [Next](#)

Scanner Preset

[Top](#) [Previous](#) [Next](#)

Descri...	Start Fr.	End Fr.	Mode	Filter	Step
VHF	144.000.000	147.000.000	FM	2	12.5 KHZ

Description : VHF

Start frequency : 144.000.000 Hz Mode FM Step 12.5 KHZ

End frequency : 147.000.000 Hz Filter 2

Select Abort Save Delete New

ScanPreset to use pre-set of scans.

[Select] Filler the values selected in the mask Scanner

[Abort] Closes the window without changing the values in the mask of the Scanner

[Save] Save the values in the fields of editing, if there is a scan with the same description will be overwritten.

[Delete] Deletes the scan with the chosen description

[New] Clear the fields of editing to facilitate the insertion of new data

Created with the Personal Edition of HelpNDoc: [Streamline your documentation process with HelpNDoc's HTML5 template](#)


Frequency to ignore

Scanner

[Top](#) [Previous](#) [Next](#)

Frequency to ignore

[Top](#) [Previous](#) [Next](#)



IC7100BKT - Frequency to ignore

Frequency Hz

Frequency Hz

Frequency Hz

Frequency Hz

Frequency Hz

Frequencies in this table will be excluded from scanning.

Created with the Personal Edition of HelpNDoc: [Upgrade your help files and your workflow with HelpNDoc's WinHelp HLP to CHM conversion](#)


Skeds

Created with the Personal Edition of HelpNDoc: [Maximize Your CHM Help File Capabilities with HelpNDoc](#)

Skeds

Skeds

[Top](#) [Previous](#) [Next](#)



Split | Memories | Scanner | **Skeds** | Bands | Set Mode | Utility | Auto CQ | Plug-In | Info

List Skeds
201105201500 ~ Test r->27

☒ Delete old skeds on startup

Descr. Time and Date UTC

VFO A Filter VFO Active

VFO B Filter

Record
Record SQL
for 30 minutes (0 for no limits)
Power OFF 30 min.

Allows to program the activation of frequencies and modes in dates and pre-arranged schedules. Thirty seconds before the programmed activation a message of warning that allows to annul the planning will appear.

- [Delete] Delete the sked selected
- [New] Emptie the fields for the input of a new one sked
- [Save] Save the sked
- [Delete skeds] Delete the skeds comprised between two dates
- [Create recur sked] Create recurrent skeds
- [Delete old skeds on startup] If checked, on program startup delete the skeds with date and time precedents

[Descr.]	Description of the sked
[Time and Date UTC]	Time and date of activation of the sked
[VFO A]	Frequency, mode and filter to use for the VFO A
[VFO B]	Frequency, Mode and filter to use for the VFO B
[Split]	Enable/Disable Split
[VFO Active]	VFO to use in reception
[Record]	No Record: does not start the audio recorder Record: starts to record the activation of the sked Record SQL: starts to record the activation of the sked recording only when the SQL is open
[Power OFF]	Select the minutes auto-off of RTX after the activation of the sked, OFF for not to activate the auto-off feature.

All the plannings are in date and time UTC and the frequencies in Hz. For a correct operation of this function it is essential that the RTX is power on in the moment of the programmed activation

Created with the Personal Edition of HelpNDoc: [Full-featured multi-format Help generator](#)


Activation sked

Skeds

[Top](#) [Previous](#) [Next](#)

Activation sked

[Top](#) [Previous](#) [Next](#)



Warning of the next activation of a sked, for interrupt the activation of a sked pressing [Abort].

Created with the Personal Edition of HelpNDoc: [Free PDF documentation generator](#)


Generate recur skeds

Skeds

[Top](#) [Previous](#) [Next](#)

Generate recur skeds

[Top](#) [Previous](#) [Next](#)



Generate a recurrence of the actual sked. To the description of every generate sked will be added "r - > nn" where nn is a progressive number.

[Repeat this sked each] Number of days between one sked and the other

[days up to] Date of end skeds creation

[Days] Valid days for the sked

[Generate] Generate the sequence of skeds

[Abort] Close the window without create sked

Created with the Personal Edition of HelpNDoc: [Easily create iPhone documentation](#)


Delete skeds

Skeds

[Top](#) [Previous](#) [Next](#)

Delete skeds

[Top](#) [Previous](#) [Next](#)



Delete all skeds programmed among the specified dates.

[Delete programmed skeds from] Time and date from which to begin to cancel, is proposed date and time of the oldest skeds

[Delete programmed skeds to] Time and Date up to which to cancel, is proposed time and date actual

Time and date UTC.


Created with the Personal Edition of HelpNDoc: [Full-featured EBook editor](#)

Bands

Functions

[Top](#) [Previous](#) [Next](#)

Bands

[Top](#) [Previous](#) [Next](#)


Radioamateurs bands in 3 groups on 4 tuning scales.

- [Bands 1] First group: 160mt - 80mt - 40mt and 30mt
- [Bands 2] Second group: 20mt - 17mt - 15mt and 12mt
- [Bands 3] Third group: 10mt - 6mt - 2mt and 70cm

Click on the pointer of tuning in order to enable the relative band.

[configure the Limits of band and mode.](#)

Created with the Personal Edition of HelpNDoc: [Import and export Markdown documents](#)

Set Mode

Set Mode

[Top](#) [Previous](#) [Next](#)

The screenshot shows the 'Set Mode' control panel with the following settings:

- Enable opening message:** ☒
- Clock:**
 - 1:
 - 2: ☒ Enabled ☐ Offset H
 -
- RTTY:**
 - Mark:
 - Shift:
 - Polarity:
- Auto Pwr:**
-
-
- Modulation input DATA ON:**
- Modulation input DATA OFF:**

The Set Mode is used to personalize the operation of the RTX.

[Set Callsign] [program registration](#)

[Enable opening message] Turns the opening message screen indication capability ON or OFF.

[Auto Power OFF] Set the power-off period for automatic shutdown, OFF for disable auto power-OFF

Clock

Management of the RTX clock

- [1] Set dates and time of the first fused hourly
 [2] Second fused
 [Enabled] Visualization on display second fused hourly
 [Offset] Offset of the second fused hourly regarding the first one from - 24: 00 to +24: 00 with steps of 5 minute
 [Synchronize with the PC clock] Use date and hour currents to set up the clock of the RTX, synchronization will be made to the exchange of the minute.

RTTY

- [Mark] RTTY Mark frequency
 [Shift] RTTY Shift width
 [Polarity] RTTY keying polarity

- [CW Setting] [Setting the CW parametres](#) and manage the memory keyer.
 [Setting] [Other settings](#) of the Set Mode

[Modulation input DATA ON] Select the input source when the DATA mode is ON (microphone, ACC connector, ACC + Microphone, USB)

[Modulation input DATA OFF] Select the input source when the DATA mode is OFF (microphone, ACC connector, ACC + Microphone, USB)


The options of personalization are many and various and will be implemented during the various versions of the program..

Created with the Personal Edition of HelpNDoc: [Transform Your Word Doc into a Professional-Quality eBook with HelpNDoc](#)

CW Setting**Set Mode**
[Top](#) [Previous](#) [Next](#)
CW Setting
[Top](#) [Previous](#) [Next](#)

IC7100BKT - CW Setting

Pitch Hz Speed WPM SSB/CW Synchronous tuning ☐

Level  Level Limit ☒ Keyer repeat time S. Keyer ratio

Paddle polarity Keyer type Rise time

Enable MIC up/down keyer (only for HM-103) ☐

Valid character: form 0 to 9 from A to Z space / ? , .
 ^ (send BT). * (Inserts contact number - can be used for 1 channel only)

Keyer Mem. 1

Keyer Mem. 2

Keyer Mem. 3

Keyer Mem. 4

Management of the parameters of configuration for the CW mode.

Valid characters for the memory keyer are: From 0 to 9, from A to Z, space, slash, interrogation mark, comma and point (/ ? , .).

Use the character ^ to send BT.

Use * to insert QSO counter (can be used in an only memory keyer).

Created with the Personal Edition of HelpNDoc: [Make Help Documentation a Breeze with a Help Authoring Tool](#)


Setting

Set Mode

[Top](#) [Previous](#) [Next](#)

Setting

[Top](#) [Previous](#) [Next](#)



The image shows the 'IC7100BKT - Setting' dialog box. At the top, there is a label 'RF/SQL Control' followed by a dropdown menu currently set to 'RF+SQL'. Below this is a section titled 'TX SSB Bandwidth' which contains a dropdown menu set to 'WIDE' and a 'Restore Default' button. To the right of this are three columns of frequency range settings: 'WIDE', 'MID', and 'NAR'. Each column has 'Lower' and 'Higher' frequency values in dropdown menus. The 'WIDE' column shows 100 and 2900; the 'MID' column shows 300 and 2700; and the 'NAR' column shows 500 and 2500. At the bottom center is a 'Close' button.

RF/SQL Control : Defines the mode of control RF/SQL (see the manual of the IC-7100 for more details)

TX Bandwidth : Sets the bandwidth in transmission (see the manual of IC-7100 for more details)


Created with the Personal Edition of HelpNDoc: [Maximize Your Documentation Capabilities with HelpNDoc's Project Analyzer](#)

Utility

Functions

[Top](#) [Previous](#) [Next](#)

Utility



The image shows the 'Utility' dialog box. It has a title bar with the word 'Utility'. The main area is divided into several sections. On the left, there are buttons for 'Register the program', 'Check for update', 'Configure band and mode limits', 'Configuration', 'Backup', 'Restore', and 'Startup'. On the right, there is a 'Prints' section with checkboxes for 'Split', 'Skeds', 'Memories', and 'Band Limits', and a 'Print' button. To the right of the 'Prints' section are checkboxes for 'QuickSet', 'Audio Rec.', 'PTT', and 'Custom Key', all of which are checked. At the bottom right is a 'Reset Window Pos.' button.

[Register the program] [program registration](#)

[Check for update] Control if new version of the program is available (require active Internet connection)

[Configure band and mode limits] Management of

[Configuration] [Configuration of the program](#) IC7100BKT

[Startup] [Select the programs](#) for running with IC7100BKT

Backup

[Backup] Save data and configuration in the file IC7100BKT_BACKUP.ZIP

[Restore] Restore data and **configuration** from a file of backup

Prints

Mark the files that are wanted to stamp and to press the key [Print]

[QuickSet] Show/Hide the [QuickSet](#) window

- [Audio Rec.] Show/Hide the [Audio Recorder](#) window
- [PTT] Show/Hide the [PTT](#) window
- [Custom Key] Show/Hide the [Custom Key](#) window
- [Reset Window Position] Reset to the default position of the various program windows


Created with the Personal Edition of HelpNDoc: [Easily create EBooks](#)

AutoCQ

Functions

[Top](#) [Previous](#) [Next](#)

AutoCQ



With AutoCQ it is possible to record up to 4 phrases that can also be reproduced in loop.

- [Record] Records the phrase.
Description of the recorded phrase or text to be transmitted in CW
- [Transmit] Transmits once the recorded phrase or text to CW
- [Loop] Repeatedly transmits at the interval chosen. Press the button to stop.
- [CW/Audio] Select the transmission mode: CW sends the text to CW, Audio: transmits the recorded phrase.
- [Pause] The pause in seconds between a transmission and the next.
- [Switch USB input while transmitting] When it starts transmitting enables USB input, at the end, rehabilitates the previous mode.
- [Enable CW Semi BK-IN] When it begins broadcasting in CW setting Semi BK-IN mode, after resetting the previous mode.

Created with the Personal Edition of HelpNDoc: [Easily create PDF Help documents](#)

Plug-in

Plug-in

[Top](#) [Previous](#) [Next](#)

Plug-in

[Top](#) [Previous](#) [Next](#)



Management of Plug-In and external programs.

[Config.] [Configure Plug-In/programs](#)

The Plug-in they are additional programs that interact with IC7100BKT, however, can be added like Plug-In whichever program.

Created with the Personal Edition of HelpNDoc: [Free CHM Help documentation generator](#)


Plug-In Management

Plug-In

[Top](#) [Previous](#) [Next](#)

Plug-In Management

[Top](#) [Previous](#) [Next](#)



[Plug-in](#) configuration.

[Name] Name of Plug-in
[Description] Description of the Plug-in functions

[PlugIn/Program] [...]	Command line of execution of Plug-in/program comprised of full path Look in the folders to the search of Plug-in
[OK]	Returns to the program
[Delete]	Remove from the selected directory Plug-in (does not cancel Plug-in from the disc)
[Save]	Saves the modifications carried out to Plug-In selected
[Copy in StartUp]	Copy selected Plug-in in the group of programs Start and it will come executed to the IC7100BKT start

Created with the Personal Edition of HelpNDoc: [Transform your help documentation into a stunning website](#)

OnAir

Funzioni

[Top](#) [Previous](#) [Next](#)

On Air

[Primo](#) [Precedente](#) [Prossimo](#)

The screenshot shows a web-based control interface for 'OnAir' status. It is divided into two main sections: 'HrdLog' and 'EnzoLog'.
HrdLog Section:
 - 'Enable OnAir' checkbox is unchecked.
 - 'Callsign' field contains 'IZ2BKT'.
 - 'Radio' field is empty.
 - 'Refresh' dropdown is set to '30' seconds.
 - 'Enable Cat' checkbox is checked.
 - 'Code' field contains '*****'.
 - 'Mode' field is empty.
 - There is a blue link 'DX Cluster' and a 'Send Now' button.
EnzoLog Section:
 - 'Enable' checkbox is unchecked.
 - 'Callsign' field contains 'IZ2BKT'.
 - 'Radio' field is empty.
 - 'Refresh' dropdown is set to '35' seconds.
 - 'Password' field contains '*****'.
 - 'Mode' field is empty.
 - There is a 'Send Now' button.

Send via internet the On-Air status with frequency and operating mode in HrdLog and EnzoLog
 If enabled, it adds some CAT features to HrdLog

[Enable] Enable / disable the automatic sending of the state

[Callsign] Callsign used in HrdLog or EnzoLog

[Code] Only HrdLog, enter the upload code received at registration on HrdLog

[Password] Only EnzoLog, enter the password to access EnzoLog

[Radio] Enter a descriptive text of the transceiver, if blank will be sent the description of the selected radio in configuration

[Mode] Mode, if blank will be sent to the current operating mode

[Refresh] Interval in seconds for sending a new state

[Send Now] Send status immediately

[Enable Cat] Enable the CAT interface to HrdLog, for example clicking on the frequency in the cluster page tunes the rtx (requires Microsoft .NET Framework 4)

[DX Cluster] Opens in the browser HrdLog DX clusters

On-Air operation requires an internet connection

More information about the On-Air are available on HrdLog and EnzoLog

Created with the Personal Edition of HelpNDoc: [Protect Your Confidential PDFs with These Simple Security Measures](#)

Hook Clipboard

Functions

[Top](#) [Previous](#) [Next](#)

Hook Clipboard

[Top](#) [Previous](#) [Next](#)


To activate the Hook Clipboard means to intercept the data that are copied in the clipboard of Windows through the command Copy or pressing CTRL+C after having selected a text. After having intercepted them, they are analyzed and, if considered valid, that is that they contain an inclusive number in the range of frequency of the Icom 7000, they are used for setting frequency and operational mode in accord with the settaggio of the limits of band and mode.

The principal purpose of this function is I data exchange data with programs DXCluster.

Example of use with the program RxClus:

- 1) Activate the function Hook Clipboard
- 2) Activate RxClus
- 3) When it passes an interesting spot, select the frequency and press the keys Ctrl+C, the RTX will be planned on this frequency.

DX de G1HWY:	28689.0	K7QQ	WA	1551Z
DX de IK7AFM:	28654.8	N4ZZ	TN	1551Z
DX de I28BRI:	28690.0	WA4TII		1604Z

Select the frequency and press CTRL+C

For a correct exchange of data it is necessary to correctly shape the parameters <Communication with the Clipboard> in the [mask of configuration](#), besides to use the mask of [Setting Limits of band and mode](#) to select the mode of transmission corrected in base to the frequency of the spot.

Created with the Personal Edition of HelpNDoc: [Maximize Your Documentation Capabilities with HelpNDoc's User-Friendly UI](#)


PTT

Functions

[Top](#) [Previous](#) [Next](#)

PTT

[Top](#) [Previous](#) [Next](#)



Click on the microphone for switch transmission/reception, or, to press the chosen key in [configuration](#).

- [Setup] Open the [mask of configuration of the PTT](#)
- [1750Hz] Switch in transmission mode and send one note of 1750Hz for 1 second (need the [connection of the audio card](#) with the RTX)
- [Tune] Selects operating mode and power specifies in [configuration](#) and switch in transmission for the seconds configurate
- [Auto Tune] Start or Stop the automatic antenna tuner, requires an automatic tuner as the AT-180, the AH-4 or equivalent.

Tx Time

Reset the counter time of TX

- [Partial] Time of transmission from the start of this session of the program
- [Total] Time of transmission from the last time [Reset]

Created with the Personal Edition of HelpNDoc: [Single source CHM, PDF, DOC and HTML Help creation](#)


Recorder audio

Functions

[Top](#) [Previous](#) [Next](#)

AudioRecorder

[Top](#) [Previous](#) [Next](#)



The AudioRecorder is a digital recorder. For a corrected operation it must connect the audio card of the PC with the RTX (to see [connection](#)), one just chosen of the CoDec is also a lot important to use for the recording (to see [audio configuration](#)).



[Audio configuration.](#)

Starts/stops the recording.

Suspends/resumes the recording or the reproduction.

Starts/stops the reproduction.

[Record only if SQL OFF] If checked, it starts the recording only in presence of a signal (SQL OFF) and suspended when the signal interrupts (SQL ON).

[File] It is possible to specify a file audio, if he leaves AUTO, to the beginning of every recording, will be produced a file by the name BKTymmddhhmmss.WAV, where yy=year, mm=month, dd=day, hh=hour, mm=minute, ss=second of beginning recording. Leaving AUTO and starting the play is opened a window from which to select the file to reproduce.

Created with the Personal Edition of HelpNDoc: [What is a Help Authoring tool?](#)

QuickSet

Functions

[Top](#) [Previous](#) [Next](#)

QuickSet

[Top](#) [Previous](#) [Next](#)

QUICKSET	
Store	
1 SSB 3.5MHz	11 JT65A 3.5MHz
2 SSB 7MHz	12 JT65A 7MHz
3 SSB 14MHz	13 JT65A 10MHz
4 SSB 18MHz	14 JT65A 14MHz
5 SSB 21MHz	15 JT65A 18MHz
6 SSB 24MHz	16 JT65A 21MHz
7 SSB 28MHz	17 JT65A 24MHz
8 SSB 50MHz	18 JT65A 28MHz
9 SSB 144MHz	19 JT65A 50MHz
10 SSB 430MHz	20 Test

IC7100BKT - Quick Set Store	
Select Button Number :	1
Description	Test
Store	Abort

Each of the 20 keys stores: Frequency, Mode, VFO in use, Attenuator, Preamplifier, SQL, Power, RF, Filter, NR, NB and ANF.

Pressing the [Store] saves the current values of Frequency, Mode, VFO in use, Attenuator, Preamplifier, Squelch, Power, RF, Filter selected, NR, NB ANF and Compressor Mic State in the chosen key.

DV - DStar

IC7100BKT - DV

My Call sign

IZ2BKT

note

7100

Apply

Load

JR

CQCQCQ

R1

IR4MO C

R2

IR4MO G

Apply

Tx Message

Mauro JN55CE

Apply

DV RX Call Signs

08/09/14 17:29:14 -> IR4MO G - - IZ2BKT - IR4MO G - IR4MO C

08/09/14 17:29:19 -> IR4UBP B - - IZ2BKT - IR4UBP B - IR4UBP B

08/09/14 17:29:23 -> IR2UBG G - - IZ2BKT - IR2UBG G - IR2UBG B

08/09/14 17:29:28 -> IR4MO G - - IZ2BKT - IR4MO G - IR4MO C

DV RX Messages

08/09/14 17:29:13 -> Mauro JN55CE - -

08/09/14 17:29:18 -> Mauro JN55CE - -

08/09/14 17:29:23 -> Mauro JN55CE - -

08/09/14 17:29:27 -> Mauro JN55CE - -

Always active

☐

Keep in front

☒

This window is activated when you select the DV mode.

Each line of input data must be set in the transmitter by clicking on the Apply button.

The Load button reads and displays the data stored in the transmitter.

Created with the Personal Edition of HelpNDoc: [Save time and frustration with HelpNDoc's WinHelp HLP to CHM conversion feature](#)

Custom Key

Function

[Top](#) [Previous](#) [Next](#)

Custom Key

[Top](#) [Previous](#) [Next](#)

The Custom Key configuration window displays six slots for assigning commands to custom keys. Slot 1 is pre-filled with 'Swap VFO A/B'. Slots 2 through 6 are empty.

Slot	Command
1	Swap VFO A/B
2	
3	
4	
5	
6	

The Custom Keys are programmable keys with CI-V commands (for a list of commands CI-V, see the manual RTX)

Click the button to send the command previously stored instead to change or enter a new command, click on the button with the right mouse button.

The Custom Key Editor dialog box allows users to edit the description and command for a specific custom key. The 'Description' field contains 'Swap VFO A/B' and the 'Command' field contains '07B0'. There are 'Save' and 'Abort' buttons at the bottom.

Custom Key Editor

Description : Swap VFO A/B

Command : 07B0

Save Abort

The editor allows you to customize the custom key with the desired description and the command to be sent. The commands must be entered in hexadecimal and always with an even number of characters, for example, for the command 7 inert 07.

Created with the Personal Edition of HelpNDoc: [Maximize Your Documentation Capabilities with HelpNDoc's Project Analyzer](#)

Various

Created with the Personal Edition of HelpNDoc: [Make Documentation a Breeze with a Help Authoring Tool](#)

List

Various

[Top](#) [Previous](#) [Next](#)

List

[Top](#) [Previous](#) [Next](#)

List of selected value

Created with the Personal Edition of HelpNDoc: [Generate Kindle eBooks with ease](#)

DTCS

Various

[Top](#) [Previous](#) [Next](#)

DTCS

[Top](#) [Previous](#) [Next](#)

IC7100BKT - Select DTCS code ✕

023	072	152	244	311	412	466	631
025	073	155	245	315	413	503	632
026	074	156	246	325	423	506	654
031	114	162	251	331	431	516	662
032	115	165	252	332	432	523	664
036	116	172	255	343	445	526	703
043	122	174	261	346	446	532	712
047	125	205	263	351	452	546	723
051	131	212	265	356	454	565	731
053	132	223	266	364	455	606	732
054	134	225	271	365	462	612	734
065	143	226	274	371	464	624	743
071	145	243	306	411	465	627	754

Tx Polarity
 ▾

Rx Polarity
 ▾

Select Tx Polarity, Rx Polarity and click on the wished code.

Created with the Personal Edition of HelpNDoc: [Free Web Help generator](#)

Tone

Various

[Top](#) [Previous](#) [Next](#)

Tone

[Top](#) [Previous](#) [Next](#)

IC7100BKT - Select Tone ✕

67.0	79.7	94.8	110.9	131.8	156.7	171.3	186.2	203.5	229.1
69.3	82.5	97.4	114.8	136.5	159.8	173.8	189.9	206.5	233.6
71.9	85.4	100.0	118.8	141.3	162.2	177.3	192.8	210.7	241.8
74.4	88.5	103.5	123.0	146.2	165.5	179.9	196.6	218.1	250.3
77.0	91.5	107.2	127.3	151.4	167.9	183.5	199.5	225.7	254.1

Click on the code of wished Sub-Tone.


Created with the Personal Edition of HelpNDoc: [Keep Your PDFs Safe from Unauthorized Access with These Security Measures](#)

DUP

Various

[Top](#) [Previous](#) [Next](#)

DUP

[Top](#) [Previous](#) [Next](#)

Input the DUP value and press [OK].


Created with the Personal Edition of HelpNDoc: [Elevate Your Help Documentation with a Help Authoring Tool](#)

Chosen VFO

Various

[Top](#) [Previous](#) [Next](#)

Chosen VFO

[Top](#) [Previous](#) [Next](#)

Select the VFO currently in reception.

Created with the Personal Edition of HelpNDoc: [Effortlessly Convert Your Markdown Content with HelpNDoc](#)

OFF-LINE Mode

Various

[Top](#) [Previous](#) [Next](#)

OFF-LINE Mode

[Top](#) [Previous](#) [Next](#)




No communication with the radio.

[Exit] Close the program

[Power On] Try to turn on the radio

[Work off line] Use the program not connected to the RTX, the modifications to the memory database will not be reflected in the RTX until the next [Synchronization](#)



For return ON-LINE use the Synchronize key in [main window](#).

Created with the Personal Edition of HelpNDoc: [Free EPub producer](#)


Band Stacking

Various

[Top](#) [Previous](#) [Next](#)

Band Stacking

[Top](#) [Previous](#) [Next](#)



[Recall]

Loads frequency and operating mode previously saves in this operating stack

[Save]

Saves frequency and operating mode in the operating stack chosen

The triple operating stack allows to save three comprehensive memories for frequency band and operating mode.


Created with the Personal Edition of HelpNDoc: [Revolutionize Your Documentation Output with HelpNDoc's Stunning User Interface](#)

Numerical Input

Various

[Top](#) [Previous](#) [Next](#)

Numerical Input

[Top](#) [Previous](#) [Next](#)

Input a value comprised between the values specifies and press the Enter key, to cancel the input press ESC .


Created with the Personal Edition of HelpNDoc: [Elevate Your Documentation Process with HelpNDoc's Advanced Features](#)

Progress Indicator

Various

[Top](#) [Previous](#) [Next](#)

Progress Indicator

[Top](#) [Previous](#) [Next](#)

Pointer of progress of the operation in course.

Created with the Personal Edition of HelpNDoc: [Leave the tedious WinHelp HLP to CHM conversion process behind with HelpNDoc](#)

Function Full Version

Various

[Top](#) [Previous](#) [Next](#)

Function Full Version

[Top](#) [Previous](#) [Next](#)



The chosen function is available only in [Full version](#), however, if you have registered the Free version the received key allows to try these functions for a sure period.

[Register the program] Opens [window to load the registration key](#) or to have information on the program registration
[Continue] The execution of the program continues, the function won't be executed

Created with the Personal Edition of HelpNDoc: [Easily create EBooks](#)

Remote management by TCP/IP

Created with the Personal Edition of HelpNDoc: [Easily share your documentation with the world through a beautiful website](#)

Remote management by TCP/IP


Remote management by TCP/IP

[Top](#) [Previous](#) [Next](#)

The remote management by TCP/IP is managed through two separate moduls:

1. Server [BKTServer](#)
 Running on the computer connected to the RTX.
2. Client [BKTClient](#)

Is necessary opening the communications port (default 7060 TCP) on the firewall.



Created with the Personal Edition of HelpNDoc: [Easy to use tool to create HTML Help files and Help web sites](#)

BKTCClient

Created with the Personal Edition of HelpNDoc: [Say Goodbye to Documentation Headaches with a Help Authoring Tool](#)


Access Control

BKTCClient

[Top](#) [Previous](#) [Next](#)

Access Control


[Top](#) [Previous](#) [Next](#)



BKTCClient start window.

[Connect to] Address IP of the PC server
[Password] Password connection, only used if required by the server.

- [Connect to startup] If selected not shown this window but connect directly to the server.
 [Setup] [BKTClient configuration.](#)
 [Connect] Starts the connection to the server.
 [Exit] Closes the program.
 [Off-Line] Executes IC7100BKT or IC706_BKT without connecting it to the server.



Wait of the connection to the server.

Created with the Personal Edition of HelpNDoc: [Maximize Your PDF Protection with These Simple Steps](#)


BKTClient

BKTClient

[Top](#) [Previous](#) [Next](#)

Select

[Top](#) [Previous](#) [Next](#)



For enable the driver BKTClient to select BKTCLIENT.DLL as Port in the serial port configuration of the program IC7100BKT, IC7000BKT or IC706_BKT.

[Driver Setup] [Configure the BKTClient.](#)

Created with the Personal Edition of HelpNDoc: [Easily create HTML Help documents](#)

Configuration

BKTClient

[Top](#) [Previous](#) [Next](#)

Configuration

[Top](#) [Previous](#) [Next](#)

BKTClient - Setup

Server: PC2

Port Com.: 7060

Local IP: 192.168.070.001 (only if there are more than one LAN card)

Enable Audio Support: ☐

Send audio only when the PTT is ON: ☒

Audio input: Default

Audio output: Default

Password: *****

OK Cancel


[Server]	IP address of the PC server with in execution BKTServer
[Port Com.]	LAN port of communication
[Local IP]	If you have multiple LAN cards you can specify the local IP address.
[Enable Audio Support]	Enables the receipt/ transmission of the audio. For a correct working the server pc must have the audio card connected to the RTX, the pc client uses the microphone to transmit. Is not possible transmit audio file
[Send audio only when the PTT is ON]	Will transmit the audio from the client toward the server only when the PTT is active, this allows to have a lower band transmission
[Audio input]	Select the audio card which the microphone is connected on and enable the microphone entry from Windows mixer
[Audio output]	Select the audio card where to listen to the audio received from the server, regulate the volume using Windows mixer
[Password]	Password connection, only used if required by the server

Created with the Personal Edition of HelpNDoc: [From Word to ePub or Kindle eBook: A Comprehensive Guide](#)

BKTServer

BKTServer

[Top](#) [Previous](#) [Next](#)



BKTServer must be in execution on the remote computer attached to the RTX.

[Serial Port Configuration]

Specify the parameters of connection with the RTX.

[Server Options]

Data Port:

Port LAN of listening and communication (default = 7060) (she must be opened by the firewall).

Autostart in system tray: He starts the server automatically and reduces it to icon in the system tray.

IP:

IP address of listening, if 000.000.000.000 BKTServer automatically selects the IP of the first net interface. Attention him IP choosing must be associate to a network interface of the computer where is in execution BKTServer.

[PTT]

Specifies the PTT parameters (see PTT configuration in the help of the program IC706_BKT.)

Not used for the Icom IC-7000 and IC-7100.

Change Language: Program language to use.

Check for update: Check if new version its available. Need a internet connection.

[Audio Stream Configuration]


Specify the parameters audio, increasing the values of Bits/sample and Samples/sec it will increase the fidelity of the audio but it needs greater band. Increase the Buffers if loss audio packets.

Enable password: if set only client with correct Password is available to connect.

Created with the Personal Edition of HelpNDoc: [Maximize Your Reach: Convert Your Word Document to an ePub or Kindle eBook](#)

BKTRS232 Alternative serial driver

BKTRS232 Alternative serial driver

[Top](#) [Previous](#) [Next](#)

Use this driver if you have communication problems with the RTX.

Created with the Personal Edition of HelpNDoc: [Easily create iPhone documentation](#)

Interfacing with other programs

Interfacing with other programs

[Top](#) [Previous](#)

IC7100BKT includes a DDE server compatible with the suite DXLab that allows you to communicate with different programs including [MultiPSK](#), FLDigi with [Fldigi-DXLab Gateway](#) installed, [JT65_HF](#), SpotCollector and other compatible with Commander of DXLab suite.

For a proper functioning of the DDE server requires that the program IC7100BKT is executed BEFORE any other program.

IC7100BKT include direct communication with [BBLogger](#).

Created with the Personal Edition of HelpNDoc: [Easily create CHM Help documents](#)
